

Sway Park Motorhome & Touring Caravan Hire

Pre Checks

1. Gas off at cylinder
2. Tyre Pressure checked
3. Corner Steadies [if applicable] raised
4. Chocks removed
5. Security devices disengaged
6. External lockers are locked
7. Brakes and signal lights checked
8. Wheel bolts checked
9. Fluid levels checked [oil/water/fuel]
10. Windscreen wash topped up
11. Mains cable disconnected and put away
12. Reversing camera/sensors checked
13. Mirrors adjusted
14. Windows roof lights closed and locked
15. Cupboards & doors closed
16. Fridge door locked
17. Toilet cassette cleaned
18. Water & waste tanks empty/drained
19. Smoke Detector tested
20. Fire extinguisher/blanket easily accessible
21. Fridge selector switch 12v
22. 12 volt master switch set to car or off
23. TV aerial retracted
24. Check all items in vehicle are secure [TV/gas cylinders/crockery/kitchen utensils/shower door secured]
25. All heavy items placed low down and secured

Final check outside check all items been packed away